

CO₂RE Home\$avers

Basement Insulation



Take Action on Climate Change

CO₂RE
Carbon Dioxide Reduction Edmonton

A Partner in Canada's
 **One-Tonne**
CHALLENGE
www.climatechange.gc.ca

Supporting Sponsors



Federation
of Canadian
Municipalities



Climate Change Central



Government
of Canada

Gouvernement
du Canada

Technical Support



Natural Resources
Canada

Ressources
Canada

CO₂RE Community Business Partners



About CO₂RE

Created by Edmontonians for Edmontonians...

Carbon Dioxide Reduction Edmonton (CO₂RE) is a developing organization formed to implement Edmonton's Community-Wide Greenhouse Gas Emissions (GHG) Reduction and Energy Strategy. CO₂RE is supported by the City of Edmonton and a group of local organizations dedicated to implementing the strategy and reducing greenhouse gas (GHG) emissions in our city.

The CO₂RE mission is to work with Edmonton residents, businesses, institutions and industry providing services, programs and initiatives to assist in reducing energy use, thereby reducing the levels of the GHG emissions that are responsible for Climate Change.

CO₂RE goals include:

- up to a 6% reduction in GHG emissions (from 1990 levels) by the year 2010 and
- a 20% reduction in GHG emissions (from 1990 levels) by the year 2020.

Do your part...

We can do many things to reduce our emissions – and that includes making our homes and lifestyles more energy efficient. The publications in this series are a first step, providing Edmonton with specific how-to guides on improving home energy efficiency, saving money and reducing GHG emissions.

For more ideas on how to become more energy efficient, log onto our website at **www.co2re.ca**!

Free Membership

Why get a membership? Becoming a CO₂RE member is free and the more people who join us in taking action on climate change, the faster we will achieve our goals. CO₂RE is working with local companies to offer incentives on energy-efficient products and programs to further assist homeowners. You'll also receive a regular newsletter with new ideas and updates. Sign up today at **www.co2re.ca**.

Industrial and commercial/institutional companies can contact our manager at 944-CORE (2673) to find out how they can participate.

Introduction

An un-insulated basement in a home can increase yearly heating costs by 10% to 30%. Basement walls should be properly insulated due to the fact that earth around the basement walls is not a good insulator and concrete walls easily conducts heat out. Cracks and holes in the foundation wall and the rim joist area also allow warm air to leak out and cold air in (Figure 1).




Figure 1

The table below shows the **Low, High** and **Average** yearly heating system gas usage and costs attributed to heat loss through basements.

Home Age	Low Usage	High Usage	Average Usage	Average Cost *
1900-1919	13.21 GJ	108.79 GJ	44.04 GJ	\$440
1920-1929	12.52 GJ	144.66 GJ	47.23 GJ	\$472
1930-1939	25.67 GJ	111.56 GJ	50.86 GJ	\$508
1940-1949	18.67 GJ	186.97 GJ	47.39 GJ	\$474
1950-1959	11.13 GJ	141.81 GJ	49.38 GJ	\$493
1960-1967	23.02 GJ	121.06 GJ	47.47 GJ	\$474
1968-1979	13.04 GJ	147.54 GJ	44.56 GJ	\$445
1980-1989	12.00 GJ	121.39 GJ	40.01 GJ	\$400
1990-2003	15.34 GJ	92.60 GJ	38.31 GJ	\$383

*Averaged 2004/05 natural gas costs of \$10 a GJ (Gigajoule).

An insulated basement improves its usability making it more comfortable and evenly heated while increasing resale values. You can insulate basement walls on the inside or the outside. The following table compares the advantages and disadvantages of each method.

Review the pros and cons and determine the better method for your home.

Two Methods of Insulating

	Advantages	Disadvantages
Interior	<ul style="list-style-type: none"> Smooth wall for easy finishing. Done in any weather. Space for wiring and plumbing. Landscape undisturbed. Can be done in stages to accommodate budget. 	<ul style="list-style-type: none"> Interior finishing may already be complete. Difficult if ducts and pipes are against wall. Water lines must be inside insulated wall to avoid freezing. Difficult to seal air/ vapour barrier in floor joist area. Decreased basement area.
Exterior	<ul style="list-style-type: none"> No disturbance of interior. Interior water lines protected. No loss of basement area. Even temperature reduces thermal stress on concrete. Cracks or leaks can be repaired. Fibrous or rigid insulations can act as additional drainage aid. Basement wall acts as thermal mass, storing heat in the house. Effectively insulates joist area. Allows placement of missing or damaged weeping tile. 	<ul style="list-style-type: none"> Requires extensive digging. Difficult near patios, steps and decks. Disturbs landscaping. Excavation is physically demanding. Shifting or settling backfill can damage insulation. Must be done in warm weather. Uses more expensive materials. Must be completed quickly in case of rain (flooding).

If there are any signs of exterior water penetration, water staining or moisture (wetting) present, you have an exterior problem such as foundation cracks or a faulty drainage field around the basement walls.

Adding interior insulation and finishing to a basement wall with moisture problems or water leakage is not advised as it will lead to mold and rotting problems.

Installing an inexpensive hygrometer in the basement will help identify high humidity levels possibly caused by moisture problems and let you know what is going on in your basement.

To effectively repair basement wall leakage problems almost always requires excavation (digging out) of the basement walls. If you are excavating for waterproofing, wall repair, or to repair/ replace the drain tile, then insulating the outside of the basement walls becomes the preferred method.

Basement Insulation

The following five example tables show the average reductions in heating system gas usage, costs and greenhouse gas (GHG) emissions achievable by insulating basement walls to an RSI 2.1 (R12) insulation level (floor to ceiling).

Gas usage savings and greenhouse gas (GHG) emission reduction figures were derived from the analysis of the results from 4,000 Edmonton area EnerGuide for Houses (EGH) home assessments.

For homes built prior to 1981 the savings potentials are reasonable. Homes built after 1981 (Alberta Building Code) were required to have a minimum insulation level of RSI 1.4 (R8) for above grade portions of basement walls. Local building practice for 1990 and newer homes is usually RSI 2.1 (R12) insulation for above grade basement walls.

The approximate cost of framing and insulating materials to insulate an unfinished basement on the inside of a 110 square metres (1200 square feet) bungalow is in the \$950 to \$1100 range. This price does not include the cost for interior finishes such as drywall or panelling or labour.

The cost for materials to insulate the same sized bungalow on the exterior of the foundation would be in the \$1300 to \$1600 range not including the increased labour and excavation costs.

Material cost for larger homes or those with more complex foundations are higher but the savings and GHG reductions achieved would be proportionately higher.

Example 1 – Homes 1900 to 1939

EnerGuide Results	Gas (GJ)	Yearly Costs	Tonnes GHG
Average Gas Usage	47.38	\$473.80	2.35
Potential Gas Savings	17.52		
Potential Cost Savings *		\$175.20	
GHG Savings ** (CO ₂)			0.87

Cost savings of \$175 and GHG emission reductions of 870 kilograms/ yearly.

Example 2 – Homes 1940 to 1967

EnerGuide Results	Gas (GJ)	Yearly Costs	Tonnes GHG
Average Gas Usage	48.08	\$480.80	2.38
Potential Gas Savings	14.72		
Potential Cost Savings *		\$147.20	
GHG Savings ** (CO ₂)			0.73

Cost savings of \$147 and GHG emission reductions of 730 kilograms/ yearly.

Example 3 – Homes 1968 to 1979

EnerGuide Results	Gas (GJ)	Yearly Costs	Tonnes GHG
Average Gas Usage	44.56	\$445.60	2.21
Potential Gas Savings	8.07		
Potential Cost Savings *		\$80.70	
GHG Savings ** (CO ₂)			0.40

Cost savings of \$80 and a GHG emission reduction of 400 kilograms/ yearly.

Example 4 – Homes 1980 to 1989***

EnerGuide Results	Gas (GJ)	Yearly Costs	Tonnes GHG
Average Gas Usage	40.01	\$400.10	1.98
Potential Gas Savings	3.39		
Potential Cost Savings *		\$33.90	
GHG Savings ** (CO ₂)			0.17

Cost savings of \$34 and a GHG emission reduction of 170 kilograms/ yearly.

Example 5 – Homes 1990 to 2003***

EnerGuide Results	Gas (GJ)	Yearly Costs	Tonnes GHG
Average Gas Usage	38.31	\$383.10	1.90
Potential Gas Savings	1.56		
Potential Cost Savings *		\$15.60	
GHG Savings ** (CO ₂)			0.08

Cost savings of \$15 and a GHG emission reduction of 80 kilograms/ yearly.

* Based on costs of \$10/ GJ (2004/05 costs)

** Greenhouse Gas (GHG) Emission savings based on average gas usage savings.

*** In 1981 Alberta Building Code for residential construction requires a minimum insulation level of RSI 1.4 (R8) for above grade portions of basement walls.

Getting Started

The Alberta Building Code requires that new homes have a minimum RSI value (metric insulation value, the higher the better) of 1.4, which is equivalent to R8 (imperial insulation value) from the top of the basement wall to 600mm (24 inches) below ground level. A minimum recommended insulation value for basement walls to maximize energy efficiency is RSI 2.1 (R12).

Familiarize yourself with the basic parts of a foundation wall (Figure 2). The drawing shows an older construction method where floor joists are embedded in the concrete foundation. The more common technique used today is platform framing, where floor joists rest on top of a wood plate, that is anchored to the concrete foundation.




Figure 2

Check for leaks before insulating, any serious water leakage usually require repairs to be completed on the outside of the basement walls.

For most homes the most common method is insulating from the interior. Information is also included on exterior insulation. For additional installation details contact manufacturers or local distributors of exterior basement insulation products and systems. Additional how-to information is available in the attached "Additional Information Sources" on the last page of this booklet.

For interior insulation increasing the RSI value to 2.1 or 3.5 (R12 to R20) down the complete wall provides the greatest energy saving.

Upgrading insulation and wall finishes are considered an "improvement". Contact the City of Edmonton at www.edmonton.ca or call (780) 496 3100 to obtain any necessary building or development permits.

Interior Basement Insulation

If your basement has had no work done on it, starting the job is easy. Chances are some wall finishing has been done. If there is no proper air/ vapour barrier or a moisture barrier on the foundation wall and little or no insulation, it is best to remove these finishes.

This allows you to check for moisture, apply a moisture barrier to the interior of the foundation wall (up to grade level) and to adequately seal and insulate the joist spaces.

Two Methods of Insulating the Interior

1. The most common method uses wall framing filled with glass fibre batts. This method is described here in detail.
2. The second involves fastening rigid board insulation to the wall. A number of fastening systems are available. Check with the local distributor or manufacturer of rigid insulation material for its recommended method of application.

Note: The Alberta Building Code requires foamed plastic materials to be covered with a fireproof layer of drywall or plaster.

Tools Needed

- Basic carpentry tools (hammer, saw, level, etc.).
- Sharp knife.
- Caulking gun and stapler.
- Drill, masonry bit and concrete anchors.
- Safety and protection equipment: a hard hat, goggles, gloves and a breathing mask should be used when working with power tools and installing some insulation materials.

Sealing the Walls

It is easier to seal wall and joist spaces before you start framing or applying rigid insulation. Figure 3 shows where to caulk in sill-plate and rim joist areas. Be sure to seal around wires, pipes, ducts or conduits that penetrate walls or rim joists.




Figure 3

Fill larger gaps with a foam backer rod or polyurethane spray foam to provide a solid backing for caulking (Figure 4).

Canned polyurethane foam can be used as an alternative to caulking to both seal and insulate larger gaps. **It must be covered with 12 mm (1/2 inch) drywall or equivalent for fire protection if exposed to the inside of the house.**




Figure 4

Use a good quality, durable caulking material that is compatible with concrete. See the *HomeSavers – Caulking and Weatherstripping* booklet for more information on caulking materials and methods of application.

Moisture Barrier

The moisture barrier is generally placed on the inside of the foundation wall to protect the insulation and framing materials from water damage.

In older basements the moisture barrier provides insurance against water damage in the wall. Whether it is really necessary depends on the type of drainage and soil type around the foundation. Clay soils tend to hold water so the moisture barrier is good insurance against future basement wall problems.

In newly poured basements the large amount of moisture in the concrete can collect behind a polyethylene moisture barrier (if it is installed immediately), run down the barrier, and out of the bottom. To avoid this, either leave the basement walls open for one year to dry out or insulate from the exterior.

The moisture barrier is usually polyethylene or a waterproof coating. It must extend from the ground or grade level down to the basement floor and under the bottom plate.

It is important that this barrier extends only up to or slightly above the exterior grade level to prevent trapping moisture within the framed wall (Figure 5).




Figure 5




Figure 6

Polyethylene is attached to the wall with acoustical sealant and a plywood nailing-strip. Waterproof coatings must be applied prior to starting construction.

In both cases, the bottom plate of the framing should be protected from the concrete with a strip of polyethylene (Figure 6).

Basement Wall Framing

Use wall framing of 2 x 4's at 400 mm (16 inches) or 600 mm (24 inches) on centre to provide an insulation cavity, wiring space and support for the interior finish.

The interior face can be placed 90 mm (3.5 inches) in from the foundation wall for RSI 2.1 (R12) batt insulation or 140 mm (5.5 inches) for RSI 3.5 (R20) batt insulation. Framing should not touch the exterior foundation walls to reduce heat loss to the foundation through the wood.

To allow for increased insulation levels, wall framing can be spaced far enough away from the wall to provide space for two layers of insulation. One layer set horizontally between the framing and the wall and a second layer vertically between the wall studs. Use a single top and bottom plate and single members around windows.

If the foundation wall and floor are always dry, seal the bottom plate to the floor. Use caulking or a gasket material to prevent warm air from leaking under and up the foundation wall behind the insulation. Bi-level homes are a special case.

Two techniques for framing them are shown in Figure 7.

Framing around stairwells and landings may also pose problems. Each situation is unique and you may have to improvise. **Always place the air/ vapour barrier on the warm side (interior wall surface) of the insulation.**




Figure 7

If possible, place the framing behind any pipes or ducts close to the foundation walls to prevent freezing (Figure 8). **Be sure not to leave any pipes or drains on the outside of the insulation layer.** If moving them is necessary many plumbing reference books outline simple drainage and water line renovations.




Figure 8

Electrical panels or gas and water meters may pose particular problems. Moving them requires qualified personnel and may be expensive. The simplest solution is often to just insulate and frame as closely as possible to the unit. Thinner rigid insulation pieces may be slipped behind pipes or lines.

Be careful near electrical panels since they are still “live” even when the main switch is off. A qualified electrician or a capable homeowner can do the electrical work (reference books are available to aid in wiring design and layout). **Be sure to obtain the necessary permits and inspections.**

Switch, outlet and junction boxes on outside walls should have an air/ vapour barrier installed behind them. Before proceeding, check again to make sure any holes in joist spaces or walls have been caulked to prevent air leakage.

Wall Insulation

Batt insulation is usually used because it is relatively inexpensive and easy to install in stud spaces. The stud spaces must be completely filled to prevent heat loss caused by air movement behind the insulation. Make sure you cut the insulating pieces to exact size. Be sure to fill the joist space cavity as well. Figure 9 shows different joist space configurations and has suggestions for insulating and sealing. **Note:** in wall type “C”, an air space is required above the insulation to avoid a cold floor perimeter.




Figure 9

If there are floor overhangs, as in many bi-levels or under bay or bow windows, seal well and insulate as shown in Figure 10.




Figure 10

Before proceeding, survey the wall insulation to make sure all areas have been filled. Check that the joist space has been insulated properly. **Make sure no pipes or ducts are on the cold side of the insulation.**

The Air/ Vapour Barrier

An air/ vapour barrier is essential on the inner, or warm, surface of an exterior wall. This barrier can be provided by 0.15 mm (6 mil) polyethylene. Staple the polyethylene to the framing, using only enough staples to hold it in place.

All joints (don't pull it too tight) should overlap one joist or stud space (Figure 11). Caulk all edges and overlap with a non-skinning acoustical sealant. Overlaps, joints or edges can be reinforced with a strong tape before stapling.




Figure 11

Electrical outlets should be enclosed with polyethylene before installation. A commercial polyethylene box can be purchased or make one of polyethylene. Seal the edges of the box to the wall air/ vapour barrier. Also seal the barrier around window and exterior door openings (Figure 12).




Figure 12

The Airtight Drywall Approach (ADA.) is a method that uses properly installed and treated drywall as the air/ vapour barrier. To install a drywall air/ vapour barrier, a strip of gasket material is placed along the bottom and side of the bottom plate (Figure 13).




Figure 13

Recommended gasket materials include closed-cell neoprene and saturated urethane foams. Notch the drywall around the floor joists to provide a tight fit. With caulking, seal the drywall to the sub-floor and the floor joists. Finally, tape the drywall and finish it with approved vapour-barrier paint.

No matter which method you use it is important to create as complete an air/ vapour barrier as possible. Make sure you do not accidentally puncture the poly air/ vapour barrier and repair any tears or holes in the polyethylene. If you are using the ADA method ensure that the drywall is sealed properly and that the vapour-barrier paint is applied evenly to all drywall surfaces.

There are no limitations on wall or ceiling covering unless foamed plastic insulation materials are used. **These products must be covered for fire protection with 12 mm (1/2 inch) drywall, which is securely anchored to the structure.** Suspended ceiling systems in basements can provide convenient access if repair work is required on ducts or pipes.

Exterior Basement Insulation

Retrofitting a basement from the outside is less common because of the extra work, the mess and the higher labour cost. However, for new homes or existing homes requiring major foundation repairs due to moisture penetration or water leakage problems exterior insulating may be practical.

Exterior insulating requires digging around the foundation. Mark the location and depth of utility services – underground electrical services, gas piping or telephone and cable TV hook-ups. Local utility companies provide this information.


Two Methods of Insulating the Exterior:

1. Partial depth method: place insulation against the wall down to 300 mm (12 inches) below ground. The place insulation 900 to 1200 mm (36 to 48 inches) horizontally to control lower-wall heat loss. Note: In new home construction, the Alberta Building Code requires vertical insulation down to 600 mm (24 inches) below ground level, either inside or outside the wall.
2. Full depth method: place insulation vertically down entire wall to the footings. This method is preferable as it is more effective in reducing heat loss but more difficult because a deeper trench is required.

Wall Preparation

Depending on the method chosen you'll need to dig a trench (either half depth or down to the footing around the foundations (Figure 14 shows $\frac{1}{2}$ depth). **If the black waterproofing is dried out, cracked or missing, repair the area.** Building supply stores stock bituminous (tar) coatings for this purpose.

Figure 14



Allow new waterproof coatings to dry completely before applying insulation. Inspect all wall penetrations and surface-mounted fixtures such as exhaust vents, electrical outlets, hose bibs and gas lines. These should be sealed with grout or silicone sealant. If possible, extend fixtures out from the wall to accommodate the new thickness of insulation.

Use qualified trades people to move any gas or electrical fixtures.

Carefully remove the lower portion of the siding or stucco. The top edge of the outside insulation should be a few centimetres above the line of the subfloor ensuring both the joist space and the wall below will be completely insulated. It also allows you to caulk around the rim joist where it meets the upper and lower floor.

Leave the lower edge of the siding or stucco and building paper pulled away from the wall a few millimetres so that flashing (called drip cap or J-channel) can be installed beneath it.

The flashing allows the insulation to extend beyond the line of the siding or stucco and protects the insulation from rain. The flashing should be wide enough to cover both insulation and protective coating.

Slip the flashing into place under the existing siding or stucco and building paper before the wall insulation is installed. The bottom siding nails may have to be removed before slipping the flashing in place. After the insulation and protective covering are in place, lower the flashing slightly and attach with roofing nails. The secured flashing provides a waterproof cap for wall insulation and wall joint.

It may not be possible to remove the stucco or siding above the level of the subfloor. Place the outside insulation as high as possible. The un-insulated portion, usually the rim joist area, can be insulated and sealed on the inside (see Figure 9).

Wall Insulation

Materials suitable for insulating outside foundation walls include extruded or expanded polystyrene and rigid glass fibre. Expanded polystyrene, also known as bead board, is available in different densities. **Type 1 has the lowest density and is not recommended for below grade applications.**

Extruded and expanded (except Type 1) polystyrene can be used underground for both vertical and horizontal applications. Rigid glass fibre boards are also available that can be installed vertically to the foundation wall.

The method for applying rigid insulation to basement walls depends on the type and thickness of the insulation and the soil conditions. Check with your local distributor or the manufacturer for installation recommendations.

Considering the work and costs involved exterior insulation should have a minimum value of RSI 1.8 (R10).

Wall Covering

Any exposed exterior insulation must be protected to avoid damage from lawnmowers or garden tools. Some rigid insulation materials will deteriorate if not protected from prolonged exposure to sunlight. Various materials can provide a protective covering: pressure-treated plywood, cement board, acrylic stucco, cement, brick and treated wood siding.

Stucco can be applied on wire lath attached directly to the rigid insulation. Some products do not require the wire lath and special stucco is applied directly to the insulation. Stucco can also be applied over plywood sheathing.




Figure 15

Siding materials such as plywood or cement board can be applied over 38 mm (1.5 inch) rigid insulation. Wood strapping at the top and a ledger strip at the bottom make this method more reliable.

To attach over thicker insulation, support framing must be built to provide a nailing surface (Figure 15).

You can also use siding or stucco over pressure-treated plywood. The treated plywood should extend below ground level to provide added protection for the insulation. Pressure-treated plywood can be painted to provide an inexpensive finish.

Floor Insulation

Although basement floor insulation may be hard to justify from an energy saving point of view (unless you have radiant floor heating) it can increase the comfort level considerably. Carpet with thick underlay provides a minimum level of thermal comfort. A more effective but expensive method is to build an insulated subfloor, or sleeper floor.

A word of caution: Ensure the basement is dry before insulating the floor.

Check for moisture by placing a square of polyethylene at several locations on the floor. Seal the edges with masking tape. If a damp spot occurs within 24 hours, the floor is too moist. Place a polyethylene moisture barrier on the concrete to prevent the transfer of moisture to the subfloor (Figure 16).




Figure 16

Frame and insulate the subfloor with batts or rigid board insulation. Shim the sleepers as required to obtain a level surface. Apply an air/ vapour barrier, and then install plywood sheeting and floor covering.

Summary

- Choose between exterior or interior basement insulation.
- Decide on materials, including existing materials that can be salvaged.
- Measure your requirements and obtain cost estimates.
- Obtain permits for changes to the building and electrical system.
- For interior insulating:
 - Seal wall and joist space, apply moisture barrier (to grade level only).
 - Frame wall and make required electrical, plumbing and heating changes.
 - Install the insulation, apply air/ vapour barrier and finish.
- For exterior insulating:
 - Excavate and clean wall of dirt and debris.
 - Remove siding or stucco to level required.
 - Insulate by selected method and apply wall insulation protection.
 - Backfill excavation carefully.
 - Install siding and flashing protection.
- Consider insulating the floor to provide extra comfort.

Although the yearly heating cost savings from insulating basement walls and floors is usually not very large, the additional benefits include a much more comfortable and usable living space and additional small reductions in your share of Greenhouse Gas emissions.

Additional Information Sources

Natural Resources Canada – Office of Energy Efficiency

www.oeef.nrcan.gc.ca – The Office of Energy Efficiency offers a wide range of free publications, programs and services to help Canadians save energy and reduce the greenhouse gas emissions that contribute to climate change.

EnerGuide for Houses (EGH) evaluations is a program from Natural Resources Canada. This detailed home assessment provides independent expert advice on the different systems of your home and what can be done to improve comfort, reduce energy bills, and cut down on greenhouse gas emissions that contribute to climate change. Consider having an EGH completed on your home.

Recommended Reading: *Keeping the Heat In* is a comprehensive source of energy efficiency how-to information for homeowners. This free publication is available from Natural Resources Canada. **Call toll free at 1-800-387-2000.**

Canada Mortgage and Housing Corp.

www.cmhc.ca/publications – CMHC is a valuable resource for information. The CMHC Order Desk is a one-stop shop for all free and priced publications, fact sheets, reports, videos and other CMHC resources. You can order online, or through their call centre at **1-800-668-2642.**

EPCOR

www.epcor.ca – The website contains information on energy and water efficiency with calculators, tools and downloadable publications to assist you in reducing your energy and water consumption.

Tools include a **Home Energy Audit**, a do-it-yourself home audit with a library of resources; **EPCOR House**, an animated tour of a typical home with efficiency information; and calculators for most major appliances, plus a **simple electricity calculator** and **water audit tool**. Tools are located in the EPCOR-Customer Service drop down menus.

Environment Canada

The Green Lane in Environment Canada's internet source for weather and environmental related to clean air, clean water and climate change. Visit them at www.ec.gc.ca

The information contained in this publication is provided as a public service and represents current research results and information sources available to CO₂RE and has been externally reviewed. CO₂RE and the City of Edmonton however, assume no liability for any damage, injury or expense that may be incurred or suffered as the result of the use of this publication.

Become A CO₂RE Member

We all contribute to the problem of Climate Change — and each of us can contribute to the solutions. Become a CO₂RE Member.

Membership is free and you can sign-up on the CO₂RE website at: www.co2re.ca

CO₂RE

Carbon Dioxide Reduction Edmonton

Publications Currently Available in this Series

Attic Insulation	Conserving Electricity
Basement Insulation	Heating Systems
Caulking and Weather-stripping	Ventilating Your Home
Condensation Concerns	Water Conservation
	Windows

Publications Available Spring 2005

Transportation	Eco-efficient Landscaping
Crawlspace Insulation	New Homes
Re-siding for Energy Conservation	Green Power
	Storey-and-a-Half Insulation



Office of the Environment

2nd flr, Century Place

Edmonton, Alberta

Contact by phone:

944-CORE (2673)



Printed on recycled paper
containing 30% post-consumer fibre.